

★ IMPORTANT OPERATIONAL PROCEDURES ★

When using Gycor's Filter Pads, the following **Important Operational Procedures** should be followed to obtain optimum performance!

- **CIRCULATE THE SHORTENING FOR NO MORE THAN FIVE (5) MINUTES**

The filter pads are designed to be circulated for a maximum of 5 minutes. Circulating any longer causes the shortening to aerate which in turn leads to smoking and circulating less than 3 minutes does not allow the pads to chemically cleanse the shortening. It is important to circulate the shortening at least once or twice per day, however, it is not necessary to circulate the shortening on every filtration during the day.

- **ASSEMBLE FILTER MACHINES WITH THE FILTER PADS THE DAY OF FILTRATION**

Since the pads are very absorbent, and their effectiveness is reduced if they are exposed to moisture, DO NOT put them in a wet filter machine or leave them in a pre-assembled filter machine overnight. It is best to store the pads in a clean dry area and assemble them in a clean dry filter machine the day of filtration.

- **DO NOT ADD ANY FILTER POWDER OR SLURRY MIX TO THE FILTER PADS**

Since the powder is already in the pad, it is not necessary to add any filter powder or slurry mix to the pads or in the vats.

If you follow these tips, along with the Filtering Instructions, the Filter Pads will work well for you.

If you have any questions, Please call:

GYCOR
Customer Service
10216 Werch Drive, Suite 108
Woodridge, IL 60517
1-800-772-0660