

IMPORTANT OPERATIONAL PROCEDURES

When using Gycor's Filter Pads, the following Important Operational Procedures should be followed to obtain optimum performance!

- **CIRCULATE SHORTENING FOR NO MORE THAN 5 MINUTES**
Circulate for at least 3 minutes to allow for proper cleansing. Circulating more than 5 minutes aerates the shortening, causing smoking. Only circulate once or twice a day, not with every filtration."
- **ASSEMBLE FILTER MACHINES WITH FILTER PADS ON THE DAY OF FILTRATION**
Filter pads lose effectiveness if exposed to moisture. Do not place them in a wet machine or leave them pre-assembled overnight. Store pads in a clean, dry area and assemble them on the day of filtration."
- **DO NOT ADD FILTER POWDER OR SLURRY MIX TO THE PADS**
The filter powder is already in the pad, so there's no need to add additional powder or slurry mix to the pads or vats."

If you follow these tips, along with the Filtering Instructions, then the expected results will be achieved.

If you have any questions, please call:

Gycor Customer Service

7750 S Grant St

Burr Ridge, IL 60527

1-800-772-0660